



AMBER-SPG CABLING

Heaters



C5

outside cryostat



Connector C5M=C5F	Function	Connector SDR1	Connector SDF1-1	Connector SDF1-2
A	Heater1 +	1	1	1
B	Heater1 -	2	2	2
C	spare	3	3	3
D	Heater2 +	4	4	4
E	Heater2 -	5	5	5
R	spare	6	6	6
S	spare	7	7	7
a	spare	8	8	8
N	spare	9	9	9
M	spare	10	10	10
Y	spare	11	11	11
X	spare	12	12	12
J	spare	13	13	13
c	Heater3 -	14	14	14
b	Heater3 +	15	15	15

